

# Haylou GT7 User Manual

## How to Wear

Gently insert the earbud into the ear canal, adjust the earbud to the most comfortable wearing state.

When calling, adjust Mic towards mouth to gain a better-talking experience.

## How to Charge

For first-time use, please remove the isolation film on the charging contacts of both earbuds. Then fully charge the charging case and earbuds.

Plugin the charging cable to charge the earbuds and the charging case at the same time. The charging indicator light will be solid white when the charging case is not fully charged. The indicator light goes out after fully charged.

## Power-on

1. Take out to auto power on when the earbuds are in the case.
2. If earbuds are out of the case and in a power-off state, keep touching the MFB button for about 1.5s to power on.

## Power-off

1. The earbuds will auto power off when put in the charging case.
2. Keep touching the MFB button for 4.5s to power off.

## How to Pair

Take two earbuds out from the charging case simultaneously, then open device Bluetooth and search for "Haylou GT7", finally click it to complete the connection. Put the earbuds back into the charging case and repeat the above operation if the connection fails. After the first connection, the earbuds can be automatically connected to the last paired device (Bluetooth needs to be turned on).

**Switch between mono and stereo mode:** It is stereo mode after two earbuds are successfully connected. Put one back into the case to power off, the other

will enter mono mode. Or pick it up again to resume stereo mode.

**Manual connection: when earbuds are turned off, manually turn on both of them. Wait 2-3 seconds for them to turn on and connect to each other. Turn on device Bluetooth to connect when the light on a single earbud flashes white slowly.**

### **Functions**

Short Touch MFB button – Play / Pause music, Answer / hang up

Double touch right MFB button – Skip track forward

Triple Trough MFB button – Activate voice assistant

Double touch left MFB button – Turn on / off latency mode

### **Answer the Second Call**

When there is a new incoming call during a call, short touch the MFB button to hold the previous call and answer the second call, then double touch the MFB button to switch the call, hold the current call, switch to the previous call, and then short touch the MFB button to hang up the current call and answer the call on hold.

### **Factory Setting**

1. Put the earbuds back into the charging case and keep the charging case fully charged. Then long touch the earbuds MFB buttons for 10s;
2. Clear phone pairing record and TWS pairing record, then turn off, and complete the connection again.

### **Common abnormalities:**

1. One of the earbuds is mute: Try to put the mute earbud into the charging case and then take it out; If the problem is still not solved after the above operation, try the reset steps;
2. The earbud cannot be charged: Check whether the charging case has sufficient power; Wipe the charging contacts with a dry cloth or cotton swab;
3. The earbud cannot automatically disconnect from the mobile phone; Check whether the charging case has sufficient power. The earbud will not power off if the case is out of power and will not disconnect from the mobile phone.

## **Warning**

1. Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product.
2. Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C).
3. Keep the indicators away from the eyes of children and animals while using the earphones.
4. Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks.
5. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids.
6. Avoid any contact with liquids.

## **Note**

1. Please read this user manual carefully before using the product and please properly store it.
2. When using it for the first time, please fully charge this product.
3. Please charge the product, in case it has not been used for over two weeks.
4. Please use a certificated charger.
5. Do not wear earphones for the long term to protect your hearing.
6. Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world.

## **FCC Requirement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference;
2. This device must accept any interference received, including interference that may cause undesired operation.

## **Daily maintenance**

Please do not shower with earbuds. Do not wear them on rainy days. Do not leave them in washing machines or other extreme situations. Clean them with a dry cloth.